



Fabrimate

Coffee & Dye Stain Remover



Benefits:

- Removes impossible stains
- May be left on Nylon carpets
- Removes coffee & cordial stains

Fabrimate represents a truly remarkable breakthrough in the removal of old, difficult to remove stains such as coffee, cordial and orange juice, previously thought impossible to remove from carpets and upholstery. **Fabrimate** is specifically designed to release stains that have penetrated the carpet fibres, such as strongly bound tannins and food dyes. **Fabrimate** removes coffee, cordial, orange juice, urine, gravies and sauces, Iodine, Butadiene and many other stains. **Fabrimate** should be used in conjunction with **Fabrispot** as a prespotter for carpets. Prespot with **Fabrispot** to remove any soils and protein remnants before using **Fabrimate**.

WARNING: Hydrogen Peroxide is a moderate bleaching agent and as such should be used with caution. When exposed to the skin Hydrogen Peroxide (at the concentration used in **Fabrimate**) may temporarily bleach the skin 'white' and leave a slight tingling sensation for 1-2 hours. However, the long term effects of Hydrogen Peroxide are completely non-toxic. Indeed, Hydrogen Peroxide (at low concentrations) is used in many antiseptics, skin lotions and skin treatments. **Fabrimate** is completely biodegradable (within hours of use) and when used with caution does not pose ANY health risks.

DIRECTIONS FOR USE:

ALWAYS PRETEST BEFORE USE: Any product designed to remove dye stains from carpets has the potential to change the colour of non-colourfast carpets and fabrics. Remember that WOOL carpets are more prone to adverse colour changes than nylons and acrylics. Wear gloves and protective eyewear when using this product. Pre-clean the area using **Fabrispot** or any Whiteley's extraction detergent. Rinse with water and blot dry using an absorbent cloth.

Mix together in equal volumes a small amount of **Fabrimate** parts A & B in a spray bottle. Mix only the quantity required. Spray directly onto the stain from a distance of 5 to 10cm. Apply liberally, but do not soak the carpet. Wait until the stain has disappeared, this may take overnight. Rinse the area with clean water and a small amount of **Fabrispot** or **Fabripowr**. Repeat the procedure if necessary.

Technical Advice: For further information refer to Whiteley's **How To Clean** information for **Carpet Cleaning** located in the Industrial section of Whiteley's website, www.whiteley.com.au