



Floor Conditioner

Floor Neutraliser

Benefits:

- Neutralises alkalinity in terrazzo
- Residual neutralising action
- Actively bonds to terrazzo floor
- Low pH & solvent free
- Does not contain acetic acid



Floor Conditioner is designed to neutralise alkaline terrazzo and concrete floors before sealing with one of Whiteley's sealer range. **Floor Conditioner** contains inorganic acid salts that react and bond to the surface of the terrazzo or concrete effectively neutralising the surface.

Neutralising the floor allows the sealer to bond better to the floor, giving the sealer an increased life and higher gloss.

DIRECTIONS FOR USE:

1. Strip the floor using Zip Strip and remove the stripped polish with an autoscrubber or mop and bucket.
2. Apply **Floor Conditioner** to the floor using an autoscrubber or mop and bucket.
3. Allow it to react with the floor for 10 minutes.
4. Pick up the remaining liquid with an autoscrubber or mop and bucket.
5. Rinse the floor quickly and allow it to dry completely.
6. Apply the sealer to the floor.

Using **Floor Conditioner** guarantee's a better, more consistent sealing job every time when stripping and re-sealing Terrazzo floors.

Technical Advice: For further information refer to Whiteley's **How To Clean** information for **Maintaining Sealed Floors** and **Cleaning Non-Resilient Floors** located in the Industrial section of Whiteley's web-site, www.whiteley.com.au