



# Pafu Base Seal

## Terrazzo & Stone Sealer

### Benefits:

- Strongly adheres to Terrazzo and other stone surfaces
- Excellent levelling properties on Terrazzo
- Enhances natural colours
- Improves powder resistance in cold weather
- Scuff and mark resistant
- Slip resistant

**Pafu Base Seal** is a clear, non-yellowing, high gloss sealer (base coat) designed to provide a strong, durable, wear resistant sealing system to all types of stone floors. **Pafu Base Seal** conforms to the Australian Standard for the Slip Resistance of Pedestrian Surfaces AS 3661.

**The Problem:** Many sealers used on terrazzo do not level and adhere evenly across the terrazzo surface (cement & marble matrix). As a result many floor sealers preferentially break away from the cement matrix and 'walk-off' the floor.

**The Solution:** **Pafu Base Seal** has excellent leveling properties to firstly 'wet-out' the cement/ marble matrix and secondly provide an extremely durable bond to the surface.

**Pafu Base Seal** provides a stable base coat for **Glothane** and **Globrite** on terrazzo and stone floors.

**Preparation:** Remove old finish using **Storm** or **Zip Strip** floor strippers. To improve wetting and cleaning add 1 cup of **Tempo HD** or **Citron** neutral detergents to stripping solution. Wet scrub the floor using a high productivity black pad. When old finish has been removed pick-up with mop and bucket or autoscrubber containing clean potable water.

**Application:** Dry burnish floor before applying sealer. Apply 2 coats of **Pafu Base Seal** followed by 2 to 4 coats of **Glothane** or **Globrite** sealer finishes. Allow approximately 30 minutes drying time between coats.

**Maintenance:** Dust mop floor daily. Clean with **Tempo HD** or **Citron** neutral detergents. For best results spray buff weekly using **Start-Up** spray buffing compounds; alternatively use **Glokleen** (cleaner/maintainer) through an autoscrubber or in a mop and bucket.

**Technical Advice:** For further information refer to Whiteley's **How To Clean** information for **Stripping and Sealing Floors** and **Maintaining Sealed Floors** located in the Industrial section of Whiteley's web-site, [www.whiteley.com.au](http://www.whiteley.com.au)



**For Use On:** **Terrazzo**  
**Slate**  
**Granite**