



Resolve

Cleaner & Sanitiser

Benefits:

- Approved for use in food establishments
- Cuts through grease and soil
- Does not contain any Butyl Solvents
- Multipurpose cleaner, sanitiser and degreaser



Resolve alkaline, detergent and sanitiser designed for use as a general purpose cleaner, degreaser and sanitiser. **Resolve** is approved for use in registered food preparation establishments.

Resolve is a water soluble cleaner-degreaser which rapidly emulsifies, suspends and removes all types of animal, vegetable and petroleum oils. It is also extremely efficient at removing greases and grime in industrial, commercial and food processing areas. **Resolve** does not impart any cleaning odours.

Resolve being a non-flammable water based detergent makes the ideal replacement for solvent based cleaners- degreasers.

PRODUCT USE	DILUTION RATIO	APPLICATION
Spray & Wipe Heavy Soils Normal Soils Light Soils	1: 5 with water 1: 20 with water 1: 50 with water	Spray Bottle
Floor Cleaning	1: 50 with water	Mop & Bucket
Disinfecting	1: 50 with water	Mop & Bucket
High Pressure Washing	1: 100 with water	Pressure washer
Scrubbing Machines	1: 50 with water	Autoscrubber or slow speed polishing machine

Note: **Resolve** passes TGA option C at a dilution of 1:50 (2% v/v)

Technical Advice: For further information refer to the Industrial section of Whiteley's web-site, www.whiteley.com.au

09/03