

OBLITER8

HIGH PERFORMANCE FLOOR STRIPPER



BENEFITS:

- High performance floor stripper
- Fast acting therefore saving time
- Liquefies old sealers on contact

OBLITER8 is a new generation, fast acting and labour saving method for removing floor sealers/finishes with minimal scrubbing. OBLITER8 is low odour and rapidly penetrates old and difficult to remove sealers/finishes.

OBLITER8 contains a synergistic blend of solvents specifically designed to penetrate and remove the most stubborn polish films. Be sure to keep the surface wet at all times when stripping. OBLITER8 can be used on vinyl, vinyl asbestos, rubber, no-wax linoleum, lino tile, marble, terrazzo, ceramic quarry tiles and the most stubborn types of polish films.

DIRECTIONS FOR USE:

Depending upon the degree of sealer on the floor, OBLITER8 can be diluted as follows:

Heavy Build up: 250mL/L of water

Moderate Build up: 125mL/L of water

Add recommended amount of OBLITER8 to cold water and apply liberally to the floor. Allow to work for 3 to 5 minutes, being sure to keep the floor wet. Floor will be slippery when it's wet. Scrub the floor using a black pad. Pick up the dissolved sealer. Rinse the floor with clean water and allow the floor to dry.

OBLITER8 is a very strong stripper. Avoid extended contact with all surfaces to be stripped (i.e Use then remove).

Note: Avoid prolonged contact with metal surfaces. Always test products in a small, discrete area before large scale application.

Obliter8 - July 2014, 1

SAFETY DATA:

For further information refer to the Material Safety Data Sheet (MSDS) located on the Whiteley Industrial website: www.whiteley.com.au

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley Industrial manufactures products that comply with Australian and International environmental policies. Whiteley Industrial aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley Industrial products are supplied in 100% recyclable containers.

Whiteley Industrial and its staff are fully committed to ensuring that our Australian environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2014 This document remains property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

Obiliter8 - July 2014, 2