

ZIP STRIP

FLOOR STRIPPER



BENEFITS:

- Fast Acting Butyl stripper
- Low odour
- Caustic and residue free
- Liquefies old sealers on contact
- Safe on most types of flooring

ZIP STRIP is a fast, efficient, labour saving method for removing floor finishes and wax sealers with a minimum of scrubbing. ZIP STRIP is a low odour ammonia free stripping system. ZIP STRIP is caustic free and residue free. MOP IT ON AND WATCH IT WORK !

ZIP STRIP quickly liquefies and suspends the sealer in a liquid emulsion which is easily removed with an autoscrubber or mop and bucket. Make sure to keep the surface wet at all time when stripping. ZIP STRIP can be used on vinyl, vinyl asbestos, rubber, no-wax linoleum, lino tile, marble, terrazzo, ceramic quarry tiles and most types of flooring.

DIRECTIONS FOR USE

Depending upon the degree of sealer on the floor, ZIP STRIP can be diluted as follows:

	ZIP STRIP	Water
Heavy Build-up	1 part	4 parts
Moderate Build-up	1 part	6 parts
Light Build-up/	1 part	12 parts

Add recommended amount of ZIP STRIP to cold water and apply liberally to the floor. Allow to work for 3 to 5 minutes, being sure to keep the floor wet. In most situations it is advisable to wet scrub the floor using a black pad on an autoscrubber or a low speed machine with a black pad. Pick-up the dissolved sealer with an autoscrubber or mop and bucket. Rinse the floor with clean water and allow the floor to dry before applying the sealer. Note that since ZIP STRIP is residue free it is not absolutely necessary to rinse the floor after stripping.

Zip Strip - July 2008, 1

SAFETY DATA

WARNING: Irritant.

RISK: Harmful by inhalation, in contact with skin and if swallowed. Irritating to eyes, respiratory system and skin.

Avoid contact with skin and eyes. Avoid breathing vapour or mist.

For further information refer to the Material Safety Data Sheet (MSDS) located on the Whiteley Industrial web site: www.whiteley.com.au

HEALTH AND SAFETY STATEMENT

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT

Whiteley Industrial manufactures products that comply with Australian and International environmental policy. Whiteley Industrial aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley Industrial products are supplied in 100% recyclable containers.

Whiteley Industrial and its staff are fully committed to ensuring that our Australian environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2013 This document remains property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

Zip Strip - July 2008, 2