

BACTEX CF

SANITISER FOOD MANUFACTURE



BENEFITS:

- Concentrated Liquid Sanitiser
- Effective against gram negative bacteria
- Effective against gram positive bacteria
- Works in hard or soft water
- May be used through Foaming Devices

BACTEX CF is a concentrated cationic sanitiser designed for use in food manufacturing and food processing establishments. BACTEX CF is designed to be used as a multipurpose sanitiser and can be used on most types of materials and surfaces encountered in food processing establishments. BACTEX CF is extremely effective against both gram positive and gram negative bacteria. BACTEX CF is designed for use as a sanitising agent in conjunction with an appropriate cleaning system. The in-built detergent system incorporated in BACTEX CF is highly effective as a sanitiser in the presence of soils. BACTEX CF is safe for use on most surfaces including all metal types (both ferrous and non ferrous metals), stainless steel, plastics, glass and most other surfaces.

BACTEX CF is suitable for use in the cleaning and sanitising of stainless steel tanks, pipes, processing equipment, floors, walls, benches, etc. BACTEX CF is suitable for use in abattoirs for meat, poultry and fish products; citrus fruit and vegetable processing; canneries, food manufacturing and other food processing establishments.

DIRECTIONS FOR USE

BACTEX CF can be applied by soaking, foaming, high-pressure spray, fogging or re-circulation following CIP cleaning. Apply to surfaces and allow to stand for a minimum of 10 minutes before rinsing with potable water.

Normal Sanitising: 5mL/Litre dilution with water. (500 ppm)

Heavy Sanitising: 10mL/Litre with water. (1000 ppm)

SAFETY DATA:

Avoid contact with skin and eyes. Wear suitable protective clothing, gloves and eyes and face protection. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. In case of accident or if you feel unwell, seek medical advice immediately (show label where ever possible). For advice, contact a Poisons Information Centre (Phone: Australia 131126, New Zealand 0800 764 766) or a doctor.

For further information refer to the Safety Data Sheet (SDS) located on the Whiteley Industrial web site: www.whiteley.com.au.

HEALTH AND SAFETY STATEMENT

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT

Whiteley Industrial manufactures products that comply with Australian and International environmental policy. Whiteley Industrial aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley Industrial products are supplied in 100% recyclable containers.

Whiteley Industrial and its staff are fully committed to ensuring that our Australian environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2017 This document remains property of Whiteley Corporation Pty Ltd. Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.