

RESOLVE DISHBRITE

MACHINE WASHING DETERGENT

BENEFITS:

- In-built scale inhibitor
- Phosphate free
- In-built water softener
- Concentrated formula

RESOLVE DISHBRITE is a strongly alkaline, non-foaming liquid compound intended for heavy duty mechanical washing. It can be used for utensil and dishwashing machines and is highly effective in removing soils and stains from stainless steel, ceramic and porcelain dishes and glassware. A highly buffered alkali reserve, good wetting and excellent rinsibility all contribute to quick, sure, regular cleaning. RESOLVE DISHBRITE contains a high level of sequestrant which ensures excellent performance in hard water areas and eliminates the possibility of scale formation within the washing machine.

MAJOR ADVANTAGES:

- **Guaranteed quality cleaning:** Use of only highly effective ingredients ensures consistent quality cleaning.
- **Consistent destaining:** Highly buffered alkali level ensures sustained cleaning, destaining and the removal of ingrained surface films.
- **Better machine performance:** In-built protection mechanism aides continuous trouble-free machine operation with cleaner jets, fewer pump troubles and a dramatic reduction in machine scaling.
- **Excellent rinsibility:** Very little RESOLVE DISHBRITE is required for excellent results. The excellent rinsibility properties gives the brightest possible results with less water spotting and streaks after heavy loads.

DIRECTIONS FOR USE:

Use 2 to 5 mL per litre of water. RESOLVE DISHBRITE may be hand fed or metered with electronically metered dispensing equipment. Concentration required will vary slightly depending on the type of machine load and dilution in the cleaning solution tank during normal washing cycles. NOTE: Should machines require a rinsing compound RESOLVE DISHRINSE should be used. RESOLVE DISHRINSE is fed neat into rinse injectors where fitted to washing machines.

CAUTION: Do NOT use for manual dish washing. (For manual dish washing use Whiteley's RESOLVE DISHCLEAN dish washing liquid).

WARNING: May be corrosive to metals. Causes severe skin burns and eye damage.

8

Kitchen


General Cleaning

CHEMICAL COMPOSITION AND PROPERTIES:

Appearance	Clear colourless to pale yellow liquid
Odour	Mild
pH.....	>14
Solubility.....	Completely miscible with water
Rinsibility.....	Total
Flammability.....	Non-flammable
Dangerous Goods Classification.....	Class 8 [Corrosive] UN 1719 Caustic Alkali Liquid, N.O.S.

SAFETY DATA: Information is listed in the Safety Data Sheet.

PACK SIZE: 3 x 5 Litre

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual’s response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

8	Kitchen	 General Cleaning
----------	----------------	--