

TECHNICAL BULLETIN

BRILLIANCE August 2021 1

BRILLIANCE

SEALER/FINISH

BENEFITS:

- Reduces scuffing on floors
- Extended wear life
- Ultra high gloss levels
- Fast drying and extremely durable
- Leaves a deep, clear finish
- Non yellowing resists discolouration
- Excellent levelling properties

BRILLIANCE Sealer/finish is a one-step, high gloss polish that provides an amazing "wet look" finish.

Research into modified acrylic copolymers lead to the development of BRILLIANCE. The one-step solution eliminates the need for a sealer and a finish, and therefore generates a simple system that reduces time, labour costs and simplifies stock control. BRILLIANCE has excellent levelling characteristics allowing for an even finish with minimal effort. It is ultrafast drying and has a slip resistant D1 rating as per AS 4586:2013.

BRILLIANCE is designed for use on most hard floor surfaces including terrazzo, vinyl tiles, granite, vinyl sheeting, tiles and slate. For vinyl, BRILLIANCE offers a one-step sealer/finish and does not require a base coat. For terrazzo and stone (of which compositions can vary and requires a tough base coat) use IMPACT base seal followed by BRILLIANCE.

DIRECTIONS FOR USE:

Stripping: Remove existing polish and sealer using Xpoly8 or Zip Strip, ensuring to follow all label directions. Rinse area with a solution of Tempo HD at a dilution 9mL/L of water. After the stripped surface is dry and has been swept the surface is now ready to seal.

Sealing: Apply first coat of Brilliance using a clean polish applicator and allow 15-30 minutes drying time. Airflow and environmental conditions will influence the drying time required between coats. Apply a further 3-4 coats of Brilliance ensuring each coat is laid on a tack free surface.

If using Impact as a base coat for Brilliance, apply 1-2 coats of Impact followed by 2-3 coats of Brilliance. Buff/burnish the final coat to improve gloss and durability.

NOTE: Apply cautiously when floor temperatures are lower than 10°C. Apply thin coats of Brilliance and allow additional drying time between coats.

Cutback and Recoat: Sweep area to be cutback. Mix a solution of Tempo HD at a dilution of 17mL/L of water. Apply solution onto the surface and allow it to work for 4 to 5 minutes before wet scrubbing the area using an autoscrubber or swing buffer fitted with black or blue pads. Rinse area with clean water, ensuring all residue is removed. Allow area to dry then buff to enhance durability and gloss. Sweep area before applying 2-3 coats of Brilliance using a clean polish applicator, ensuring each coat is laid on a tack free surface. Buffing/burnishing the final coat will further increase gloss and durability.

2

Floor Sealers







TECHNICAL BULLETIN

BRILLIANCE August 2021 2

CHEMICAL COMPOSITION AND PROPERTIES:

Appearance Milky white liquid

Odour Mild

pH 9.50

Solubility Completely miscible with water

MAINTENANCE:

Daily Maintenance: Sweep floor and mop or scrub daily with Tempo HD. Use Rejuven8 2-3 times per week to improve gloss and increase durability and slip resistance. Buff/burnish floors daily.

Alternate Days: Mop and scrub floor with Tempo HD at a dilution of 9mL/Litre of water & buff [4-5 days/week].

SAFETY DATA: Information is listed in the Safety Data Sheet.

PACK SIZE: 3 x 5 Litre

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/ disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

2

Floor Sealers



