# Brilliance

## **New & Improved**

Simply Brilliant Hard Floor Finish.

## Insist on Whiteley Industrial when ordering your hard floor care products

#### **BENEFITS:**

- > NEW FORMULATION
- > Reduces Scuffing on Flooring
- > Extended Wear Life
- > Ultra High Gloss Levels
- > Fast drying and extremely durable
- > Leaves a deep, clear finish
- > Non yellowing, resists discolouration
- > Excellent levelling properties

**Brilliance** has been reformulated with improved scuff resistance and even higher gloss levels. You will see an improvement in the durability and wear life of the polish. New & Improved **Brilliance** now leads the world in high gloss hard floor finishes. Brilliance is excellent for use on hard floor surfaces including: terrazzo, vinyl tiles, granite, vinyl sheeting, tiles and slate.
Brilliance can be used as a one step sealer finish which gives contractors a simple system that is easy to maintain. Brilliance provides excellent gloss and outstanding depth.

Ground breaking research into modified acrylic copolymers has lead to the development of **Brilliance**, a product which eliminates the need for a sealer and a finish therefore reducing time and costs as well as simplifying stock control. **Brilliance** also has excellent levelling characteristics allowing for an even finish with minimal effort.





## **FLOOR STRIPPERS**

#### Xpoly8

High performance floor stripper. XPOLY8 is a low odour, fast acting, labour saving method for removing floor finishes and wax sealers with a minimum of scrubbing.

#### **Zip Strip**

Butyl based stripper, extremely fast acting. Does not require neutralising.

## **FLOOR SEALERS**

#### Brilliance

Ultra high gloss. Quick drying and extremely durable. One step system for vinyl. Provides the perfect finish for Impact for terrazzo and stone. Burnishable from 250-2000 rpm.

#### **Thermaglo Plus**

For use on all types of floors from vinyl to timber and terrazzo. One step product. Burnishable using 250 rpm to 2000 rpm machines.

#### Impact

Low maintenance sealer with a high gloss finish. A clear non-yellowing, UV resistant semi-permanent sealer for use on hard floor surfaces including vinyl, stone, tiles, terrazzo and concrete. Has excellent levelling properties and is resistant to scratching and scuffing

### **FLOOR MAINTENANCE**

#### **Tempo HD**

Heavy duty neutral detergent. Suitable for cleaning all types of floors and surfaces. Low foaming, non-perfumed formula. Provides high performance cleaning to keep floors like new.

#### **Rejuven8**

A neutral multi-purpose cleaner and maintainer designed to enhance the appearance of worn floors finishes. Increase the durability of floor finishes and enhances gloss levels. Effectively repairs scratches and reduces the appearance of scuffing - black heal marks, ground in dirt and surface scratches.

For more information visit www.whiteley.com.au or call the Product Support Hotline on 1800 833 566

## How to achieve the most durable floor finish?

Achieving a durable floor finish is best done by using Impact as a two-coat base sealer followed by four coats of Brilliance. Impact is best used in areas of high traffic such as loading docks and checkout areas because it has a high-solids formulation. It will increase the durability and longevity of the floor and will reduce the need to strip as often.

## How to spot a dirty floor?

There are two things that you need to look out for:

- > 1. A build up of debris where the floor and walls meet, and
- > 2. A loss of shine on the surface.

If there is a build up of debris you many need to review dilution rates and your maintenance schedule. If the polish has gone from the surface then it is definitely time to strip and reseal your floor. The benefit of this process is you will remove all the debris, replace the gloss especially where there is a high incidence of traffic and enhance the overall appearance of your store.

## Why does my floor look dull and scuffed?

General wear and tear caused by the rigours of daily traffic will naturally degrade the quality of the polish over time. Rejuven8 should be used in your maintenance schedule as it will replenish and protect the surface of your floor.

## How do I know when to strip the floor?

A full strip needs to be carried out when the surface of the floor can no longer be restored by routine maintenance. Use Xpoly8 for a faster emulsifying stripper.

## Are your products slip resistant?

Yes! Whiteley hard floor sealers are slip resistant according to A/NZS4663. Regular use of Rejuven8 or Glokleen in your maintenance schedule will also increase floor grip.

#### Handy Hint (for slippery floors)

Clean the floor thoroughly using Tempo HD (dilute 1 to 60), and if possible while still wet scrub the floor using a buffing machine with a blue pad. Remove the solution with a clean mop. Allow the floor to dry and then buff again using a clean red pad until the floor surface is clear. Recoat the floor surface with two light coats of Brilliance (use a dedicated polish mop and bucket).

## Why is my floor starting to look yellow?

Yellow floors are a typically an indication that you may be either using too much maintainer, or the polish is getting old and worn, especially in areas of high traffic. It is suggested that you either wash off the old maintainer, or strip and reseal to bring back the gloss to your floor.

## What is the best maintenance schedule for a sealed floor?

Use a neutral maintainer each day to extend the life of floor finishes. Daily: Sweep floor

Alternate Davis

- Alternate Days:
- > Mop or scrub floor with Tempo HD at a dilution of 8mL/Litre of water & then buff. (4-5 days/ week)
- > Mop or scrub floor with Glokleen or Rejuven8 at a dilution of 16mL/Litre and then buff. This provides extra wear and durability to the floor finish while also increasing slip resistance. ( 2-3 days/week)

## What's this flaky powder residue on my floor?

Irregularity in the floor finish is uncommon and can be detected within days of the sealer being laid. This could be because the pH is an issue, or the area where the polish is being laid is too cold or too humid. It is advised that if you live in colder regions of Australia that you plan to seal your floor in the warmer months of the year