



FABRIPOWR

PRESPRAY DETERGENT



BENEFITS:

- Excellent for use on wool and natural fibres
- Rapid penetration and emulsification of soils
- Built in biocide and odour neutraliser
- Concentrated 1:40 prespray dilution

FABRIPOWR offers superior cleaning performance without the use of alkaline boosters. FABRIPOWR effectively substitutes for up to 5 different chemicals. FABRIPOWR may be used as a carpet extraction detergent, carpet prespotter, carpet sanitiser, odour suppressor and deodouriser. Only FABRIPOWR offers carpet cleaners so much versatility with the one carpet cleaning product. FABRIPOWR is the ideal product to use on woolen carpets.

FABRIPOWR is suitable for use in both truck mount and portable carpet cleaning machines. FABRIPOWR is safe for use on most carpet fibres and provides improved economy and cheaper dilution ratios due to its concentrated nonionic surfactant blend. Do NOT use on flurochemical treated carpet fibres.

DIRECTIONS FOR USE:

PRODUCT USE	DILUTION RATE	APPLICATION
Prespray, sanitiser, odour suppressor & deodouriser	Normal soils: 25mL/L of water Heavy soils: 50mL/L of water	Spray evenly over carpet with atomising spray. For heavy soiling agitate carpet fibre. Allow to react for 10 to 15 minutes before extracting
Prespotter	Normal soils: 200mL/L of water	Apply to stain. Gently agitate working from the edge of the stain towards the centre. Soak with dry cloth or extract.

Fabripowr - July 2014, 1





DISPOSAL:

Please dispose of recovered waste water through an approved filter system. Help protect our waterways.

SAFETY DATA:

For further information refer to the Material Safety Data Sheet (MSDS) located on the Whiteley Industrial website: www.whiteley.com.au

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/ disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley Industrial manufactures products that comply with Australian and International environmental policies. Whiteley Industrial aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley Industrial products are supplied in 100% recyclable containers.

Whiteley Industrial and its staff are fully committed to ensuring that our Australian environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2014 This document remains property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

Fabripowr - July 2014, 2



