

TECHNICAL BULLETIN

TILE PLUS October 2021 1

TILE PLUS

HIGHLY CONCENTRATED DEGREASER DETERGENT

BENEFITS:

- Cuts through grease and soil
- Does not contain any butyl solvent
- Multipurpose cleaner and degreaser
- Contains corrosion inhibitor
- Rapid cleaning action
- Concentrate provides economic cleaning solution

TILE PLUS is a concentrated heavy duty alkaline detergent designed for the removal of fats and oils from floors. TILE PLUS rapidly removes carbonized food deposits and heavily congealed fats and greases.

TILE PLUS is a water soluble cleaner and degreaser which rapidly emulsifies, suspends and removes all types of animal, vegetable and petroleum oils. It is also extremely efficient at removing greases and grime in industrial, commercial and food processing areas. TILE PLUS has the added benefit of a corrosion inhibitor and does not impart any cleaning odours.

DIRECTIONS FOR USE:

PRODUCT USE	DILUTION RATE	APPLICATION
Light Floor Cleaning	8mL/L of water	Mop & Bucket
Heavy Duty Floor Cleaning	16mL/L of water	Mop & Bucket

Dilute product. Allow 5-10 minutes dwell time on tiles then agitate with stiff bristle brush or pad. Remove residue and rinse thoroughly with water. Note: Rinse area of application thoroughly with clean water to avoid any residue being left on the surface.

CHEMICAL COMPOSITION AND PROPERTIES:

Appearance:	Clear brown liquid
Odour:	Characteristic
pH (concentrate):	>14
Solubility:	Completely miscible with water
Rinsibility:	Good
Abrasives:	Nil
Hazardous Status:	May react with aluminium, tin and zinc to produce flammable hydrogen gas.
Volatility:	Nil
Flammability:	Nil
Dangerous Goods Rating:	Class 8 UN 1719 Caustic Alkali Liquid N.O.S. (Sodium Hydroxide)





TECHNICAL BULLETIN

TILE PLUS October 2021 2

CAUTION: Floor may be slippery when applying.

PRECAUTION: DO NOT use on metal surfaces or polished floors. DO NOT mix with HOT water. DO NOT use this product undiluted. DO NOT use on painted surfaces.

SAFETY DATA: Information is listed in the Safety Data Sheet.

SPILLS: Slippery when wet. Use sand or earth to prevent run off. Collect and seal in dangerous goods container. Wash remnants to drain with excess water.

FIRST AID:

For advice, contact a Poisons Information Centre [Phone: Australia 131126, New Zealand 0800 764 766] or a doctor.

PACK SIZE: 3 x 5 Litre

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have a potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/ disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

