

TECHNICAL BULLETIN

XPOLY8 November 2021 1

XPOLY8 FLOOR STRIPPER

BENEFITS:

- High performance floor stripper
- Fast acting, saves time
- Liquefies old sealers on contact
- Effective on most types of flooring

XPOLY8 is a new generation floor stripper designed to rapidly liquefy and emulsify old sealers for easy removal with an auto-scrubber or mop and bucket. XPOLY8 is a powerful dual action floor stripper designed to remove metalised and non-metalised floor finishes. XPOLY8 is a low odour, fast acting, labour saving method for removing floor sealers/finishes with a minimum of scrubbing.

XPOLY8 contains a blend of glycol solvents that synergise with a rapid penetration dual chain emulsifier to penetrate the most stubborn old polish films. Make sure to keep the surface wet at all times when stripping floors. XPOLY8 can be used on vinyl, vinyl asbestos, rubber, no-wax linoleum, lino tile, marble, terrazzo, ceramic quarry tiles and most types of flooring.

DIRECTIONS FOR USE:

Depending upon the degree of sealer on the floor, XPOLY8 can be diluted as follows:

Heavy Build up: 250mL/L of water Moderate Build up: 125mL/L of water

Add recommended amount of XPOLY8 to cold water and apply liberally to the floor. Allow to work for 3 to 5 minutes, being sure to keep the floor wet. CAUTION: Floor will be slippery when it's wet. Scrub the floor using a black pad. Pick up the dissolved sealer. Rinse the floor with clean water and allow the floor to dry.

Note: Avoid prolonged contact with metal surfaces.

SAFETY DATA: Information is listed in the Safety Data Sheet.

PACK SIZE: 3 x 5 Litre









TECHNICAL BULLETIN

XPOLY8 November 2021 2

PROFESSIONAL CLEANING COLOUR CODED GUIDE:

The Industrial product range has been streamlined to make it easier for you to choose the right product. This provides a simple, straightforward guide for finding products for specific cleaning needs. The product range has been categorised into an easy-to-use product selection chart.

To view the Professional Cleaning Colour Coded Chart visit www.whiteley.com.au/professional-cleaning-colour-codedguide

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/ disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.



Floor Strippers



