

# TECHNICAL BULLETIN

ZIP STRIP November 2021 1

## **ZIP STRIP**

#### **FLOOR STRIPPER**

#### **BENEFITS:**

- Fast acting
- Caustic and residue free
- Liquefies old sealers on contact
- Safe on most flooring

ZIP STRIP is a fast, efficient, labour saving method for removing floor finishes and wax sealers with a minimum of scrubbing. ZIP STRIP is a low odour ammonia free stripping system. ZIP STRIP is caustic free and residue free.

ZIP STRIP quickly liquefies and suspends the sealer in a liquid emulsion which is easily removed with an autoscrubber or mop and bucket. ZIP STRIP can be used on vinyl, vinyl asbestos, rubber, no-wax linoleum, lino tile, marble, terrazzo, ceramic quarry tiles and most types of flooring.

#### **DIRECTIONS FOR USE:**

Depending upon the degree of sealer on the floor, ZIP STRIP can be diluted as follows:

PRODUCT USE	DILUTION
Heavy Build-up	200mL/L of water
Moderate Build-up	143mL/L of water
Light Build-up	77mL/L of water

Add recommended amount of Zip Strip to cold water and apply liberally to the floor. Allow to work for 3 to 5 minutes, being sure to keep the floor wet. Scrub the floor using a black pad. Pick up the dissolved sealer. Rinse the floor with clean water and allow the floor to dry. Note that since Zip Strip is residue free it is not absolutely necessary to rinse the floor after stripping.

#### **ABOUT LMS:**

Our comprehensive learning platform offers a broad range of information including the latest information on Infection Prevention and Control, recommended products and cleaning processes for individual markets.



Scan to register for Whiteley's Online Learning Centre

#### **SAFETY DATA:**

Information is listed in the Safety Data Sheet.



**Floor Strippers** 







### **TECHNICAL BULLETIN**

ZIP STRIP November 2021 2

PACK SIZE: ......3 x 5 Litre

#### PROFESSIONAL CLEANING COLOUR CODED GUIDE:

The Industrial product range has been streamlined to make it easier for you to choose the right product. This provides a simple, straightforward guide for finding products for specific cleaning needs. The product range has been categorised into an easy-to-use product selection chart.

To view the Professional Cleaning Colour Coded Chart visit www.whiteley.com.au/professional-cleaning-colour-codedquide

#### **HEALTH AND SAFETY STATEMENT:**

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

#### **ENVIRONMENTAL STATEMENT:**

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.



**Floor Strippers** 



