

RESOLVE OVENCLEAN

OVEN & GRILL CLEANER

BENEFITS:

- Heavy duty concentrate
- Fast acting
- Removes carbonised deposits
- No harsh scrubbing required
- Contains sequestrants for improved cleaning

RESOLVE OVENCLEAN is a concentrated heavy duty alkaline detergent designed for the daily cleaning of ovens, grills and other cooking equipment. RESOLVE OVENCLEAN rapidly removes carbonised food deposits and heavily congealed fats and greases. RESOLVE OVENCLEAN contains sequestrants, builders and a highly efficient detergent system for easy rinsing from all surfaces. NOTE: RESOLVE OVENCLEAN is not suitable for use on aluminum surfaces and/or equipment.

DIRECTIONS FOR USE:**OVEN & GRILL CLEANING:**

1. Remove excess greases, fats and carbonised deposits with a spatula or other suitable implement and rinse with water.
2. Spray RESOLVE OVENCLEAN undiluted directly onto equipment to be cleaned. Heat equipment to approximately 80°C and leave for 5 to 10 minutes [DO NOT allow equipment to dry-out when heating].
3. Scrub with scourer and rinse off with water when clean.
4. Rinse product contacting surface with potable water after use.

CAUTION: Do not use for manual dishwashing [by hand]. Do NOT mix with HOT water.

WARNING: May be corrosive to metals. Causes severe skin burns and eye damage.

SAFETY DIRECTIONS: Wear suitable gloves and eye/face protection. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. In case of accident or if you feel unwell, seek medical advice immediately [show label where ever possible].

8

Kitchen

Gc

General Cleaning

CHEMICAL COMPOSITION AND PROPERTIES:

Appearance	Clear brown liquid
Odour	Characteristic
pH	>14
Solubility	Completely miscible with water
Rinsibility	Total
Flammability	Non-flammable
Dangerous Goods Classification	Class 8 [Corrosive] UN 1719 Caustic Alkali Liquid, N.O.S.

FIRST AID: For advice, contact a Poisons Information Centre (Phone Australia 131 126; New Zealand 0800 764 766) or a doctor. If swallowed, do NOT induce vomiting. If in eyes, hold eyelids apart and flush the eye continuously with running water. Continue flushing until advised to stop by the Poisons Information Centre or a doctor, or for at least 15 minutes. If skin contact occurs, remove contaminated clothing and flush skin and hair with running water.

SAFETY DATA: Information is listed in the Safety Data Sheet.

PACK SIZE: 3 x 5 Litre

HEALTH AND SAFETY STATEMENT:

There is no way of predicting an individual's response to cleaning or disinfecting products. All cleaning and disinfecting products have a potential to cause skin and other irritation in susceptible individuals. Direct physical contact with the skin should be avoided. If irritation does occur when using this product or any other cleaning/disinfecting solution then the individual should be removed from direct contact with the solution until a satisfactory safe working environment for that individual is determined.

ENVIRONMENTAL STATEMENT:

Whiteley manufactures products that comply with Australian and International environmental policy. Whiteley aims to ensure that every product is 100% biodegradable, whilst achieving optimal performance and benefit to customers. All Whiteley products are supplied in 100% recyclable containers. Whiteley and its staff are fully committed to ensuring that our environment and those international environs in which our products are used are enhanced by the use of technology, and that these environments are preserved for the enjoyment of future generations.

© 2021 This document remains the property of Whiteley Corporation Pty Ltd.

Alterations are not permitted without prior written authorisation from Whiteley Corporation Pty Ltd.

8
Kitchen
Gc
General Cleaning